

1、 2-eye 3-in-1 point control DMX channel menu AH60 DH61

10 channel mode (A001 status)

channel	function	explain
CH1	Total dimming	Total dimming, from dark to bright
CH2	R1 dimming	Red 1 dimming, from dark to bright
CH3	G1 dimming	Green 1 dimming, from dark to bright
CH4	Dimming B1	Blue 1 dimming, from dark to bright
CH5	R2 dimming	Red 2 dimming, from dark to bright
CH6	G2 dimming	Green 2 dimming, from dark to bright
CH7	B2 dimming	Blue 2 dimming, from dark to bright
CH8	Total stroboscopic	Global stroboscopic, from slow to fast
CH9	Select function	0: dimming mode; 1 — 62: color selection (selected by ch10); 63-124: jump; 125-186: gradient; 187-249 pulse change; 250-255: voice control (ch10 selects voice control 1 and 2)
CH10	Function speed	Function speed, from slow to fast (color selection for color output, voice control strobe and jump for voice control)

10 channel mode (D001)

channel	function	explain
CH1	Total dimming	Total dimming, from dark to bright
CH2	Total stroboscopic	Global stroboscopic, from slow to fast
CH3	Select function	0: dimming mode; 1 — 62: color selection (selected by CH4); 63-124: jump; 125-186: gradient; 187-249 pulse change; 250-255: voice control (CH4 selects voice control 1 and 2)
CH4	Function speed	Function speed, from slow to fast (color selection for color output, voice control strobe and jump for voice

		control)
CH5	R1 dimming	Red 1 dimming, from dark to bright
CH6	G1 dimming	Green 1 dimming, from dark to bright
CH7	Dimming B1	Blue 1 dimming, from dark to bright
CH8	R2 dimming	Red 2 dimming, from dark to bright
CH9	G2 dimming	Green 2 dimming, from dark to bright
CH10	B2 dimming	Blue 2 dimming, from dark to bright

2、 display menu

Serial numb	content	Numerical range	Function and description
1	A001	001- 512	DMX512 address code setting - 10 channel mode
2	d001	001- 512	DMX512 address code setting - 10 channel mode
3	r255	000 - 255	Red 1 dimming, from dark to bright.
4	G255	000 - 255	Green 1 dimming, from dark to bright.
5	b255	000 - 255	Blue 1 dimming, from dark to bright.
6	u255	000 - 255	Red 2 dimming, from dark to bright.
7	y255	000 - 255	Green 2 tone light, from dark to bright.
8	P255	000 - 255	Blue 2 dimming, from dark to bright.
9	FH99	01 - 99	Stroboscopic, speed from slow to fast.
10	CL01	01 - 173	Manual color selection mode.
11	CC99	01 - 99	Jump from slow to fast.
12	DE99	01 - 99	Gradient, from slow to fast.
13n	CP99	01 - 99	Pulse changes from slow to fast.
14	SU01	01 - 02	Mode: 1 is stroboscopic jump, 2 is jump

3、 Master slave description

In D001 or A001 state, the slave signal is automatically received without additional setting.